

Automation Instruction Guide

Insert tungsten collet into electrode case, insert inner collet into other end of tungsten collet



Insert tungsten to collets, insert into torch and complete with back cap hand tighten. Tungsten should remain tight.



Be sure red ring is on end of torch and finish with insulator and gas lens

